



# CTV

Externally threaded 2-way zone valve



The valve range is intended to be used together with the RTA(O)M100 thermal actuators or RVAZ2 electromechanical actuators for temperature control in heating and cooling systems, such as radiators, convectors, chilled ceilings etc.

- ✓ Size DN10...DN20
- ✓ Kvs value adjustable between 0.12...1.9
- ✓ Media temperature 2...90°C
- ✓ Pressure rating PN10
- ✓ Compact design

## Function

The valve is normally open. When using a NC actuator the valve is closed when no voltage is applied. Using a NO actuator will give the opposite result.

The valve is closed when the stem is in its lowest position and completely open in the highest position.




Fig. 1 2-way valve


## Setting of kvs value

The valve has a reference marking in the upper valve body. The kvs value is set using the grey plastic cap supplied with the valve.

## Installation

The valves are supplied with a grey plastic cap which can be used to open/close the valve manually during system installation. Turning the plastic cap clockwise to its end position closes the valve.

- ✓ Before installation of the control valve, ensure that the pipe is clean. Make sure that pipe scale, metal chips, welding slag and other foreign materials are removed.
- ✓ The valve should never be mounted at an angle of more than 90°.



## HEAD OFFICE SWEDEN

Phone: +46 31 720 02 00  
Web: [www.regincontrols.com](http://www.regincontrols.com)  
E-mail: [info@regincontrols.com](mailto:info@regincontrols.com)

## CTV

- ✓ Install the valve according to the fluid direction arrow shown on the valve.
- ✓ The actuator is mounted on the valve with the adapter (VA54 or 29214112001) which is sold separately.

---

**HEAD OFFICE SWEDEN**

Phone: +46 31 720 02 00  
Web: [www.regincontrols.com](http://www.regincontrols.com)  
E-mail: [info@regincontrols.com](mailto:info@regincontrols.com)

CTV

— 2 —



## Technical data

|                             |  |
|-----------------------------|--|
| <b>Application</b>          | Heating systems, cooling systems, radiators                  |
| <b>Pressure rating</b>      | PN10   |
| <b>Connection</b>           | BSP externally threaded according to ISO 228/1               |
| <b>Connection, actuator</b> | M28 x 1.5  |
| <b>Flow characteristics</b> | Linear   |
| <b>Max. leakage</b>         | 0.0 % of the kvs value                                       |
| <b>Max. diff. pressure</b>  | 150 kPa  |
| <b>Media</b>                | Hot water, cold water, glycol-mixed water (max. 30 % glycol) |
| <b>Media temperature</b>    | 2...90 °C  |
| <b>Stroke</b>               | 3.5 mm   |

## Material

|                     |                        |
|---------------------|------------------------|
| <b>Body</b>         | Chromed brass CW614N   |
| <b>Seat</b>         | Brass CW614N           |
| <b>Stem</b>         | Stainless steel 1.4305 |
| <b>O-rings</b>      | EPDM                   |
| <b>Bonnet</b>       | Brass CW614N           |
| <b>Seat packing</b> | NBR                    |

## Models

| <b>Article</b> | <b>Nominal diameter</b> | <b>Connection, external thread</b> | <b>Kvs (adjustable)</b> |
|----------------|-------------------------|------------------------------------|-------------------------|
| CTV10          | DN10                    | G½"                                | 0.12...1.14             |
| CTV15-1,9      | DN15                    | G¾"                                | 0.17...1.9              |
| CTV20          | DN20                    | G1"                                | 0.15...1.55             |

## Suitable actuators and adapters

### Electromechanical actuators

| <b>Article</b> | <b>Control signal</b>      | <b>Supply voltage</b> | <b>Adapter</b> |
|----------------|----------------------------|-----------------------|----------------|
| RVAZ2-24A      | 0(2)...10 V / (0)4...20 mA | 24 V AC/DC +/- 15%    | 29214112001    |
| RVAZ2-24       | 2-point/3-point, 3-wire    | 24 V AC/DC +/- 15%    | 29214112001    |
| RVAZ2-230      | 2-point/3-point, 3-wire    | 230 V AC/DC +/- 15%   | 29214112001    |


### Thermal actuators

| <b>Article</b> | <b>Control signal</b> | <b>Supply voltage</b> | <b>Adapter</b> |
|----------------|-----------------------|-----------------------|----------------|
| RTAM-24A       | 0...10 V DC, NC       | 24 V AC               | VA54           |
| RTAM-24        | On/Off, NC            | 24 V AC/DC            | VA54           |
| RTAM-230       | On/Off, NC            | 230 V AC              | VA54           |
| RTAOM-24A      | 0...10 V DC, NO       | 24 V AC               | VA54           |
| RTAOM-24       | On/Off, NO            | 24 V AC/DC            | VA54           |
| RTAOM-230      | On/Off, NO            | 230 V AC              | VA54           |

## Accessories

| Article | Description   | Connection | Valve     |
|---------|---------------|------------|-----------|
| 1885136 | Nut and olive | 1/2", K12  | CTV10     |
| 1886274 | Nut and olive | 3/4", K15  | CTV15-1,9 |
| 1884709 | Nut and olive | 3/4", K18  | CTV15-1,9 |
| 1886282 | Nut and olive | 1", K22    | CTV20     |

## Dimensions



| Model     | A  | B    | C  | D         | G      |
|-----------|----|------|----|-----------|--------|
| CTV10     | 54 | 1,5  | 45 | M28 x 1,5 | G 1/2" |
| CTV15-1,9 | 60 | 13   | 45 | M28 x 1,5 | G 3/4" |
| CTV20     | 68 | 16,5 | 45 | M28 x 1,5 | G 1"   |

[mm], unless otherwise specified

## Adjustable kvs value

The kvs value is set by turning the grey plastic cap until the desired number on the cap is aligned with the reference marking in the valve (see the picture below). Depending on the position number selected on the plastic cap, different kvs values are set according to the table below.



HEAD OFFICE SWEDEN

Phone: +46 31 720 02 00  
Web: [www.regincontrols.com](http://www.regincontrols.com)  
E-mail: [info@regincontrols.com](mailto:info@regincontrols.com)

CTV


— 4 —

  
**REGIN**  
THE CHALLENGER

| Model     | Position 1 | Position 2 | Position 3 | Position 4 | Position 5 | Position 6 | Position 7 | Position 8 |
|-----------|------------|------------|------------|------------|------------|------------|------------|------------|
| CTV10     | 0.12       | 0.22       | 0.34       | 0.55       | 0.7        | 0.9        | 1.07       | 1.14       |
| CTV15-1,9 | 0.17       | 0.33       | 0.50       | 0.75       | 1.0        | 1.25       | 1.65       | 1.9        |
| CTV20     | 0.15       | 0.35       | 0.55       | 0.74       | 0.9        | 1.1        | 1.36       | 1.55       |

## Pressure drop diagram

Pressure drop



The valves have adjustable kvs value (kvs = the flow in  $\text{m}^3/\text{h}$  at a pressure drop of 100 kPa).

### To draw a curve for other settings than the pre-drawn values

Draw a vertical line through the flow. The starting point of the angled line is where the vertical line intersects the top of the chart (at 100 kPa). The angled line should be parallel to the pre-drawn lines.

In the example above, the kvs value = 0.25.

## Documentation

All documentation can be downloaded from [www.regincontrols.com](http://www.regincontrols.com).